









Nikon COOLPIX Accessories

The Most Comprehensive Digital Camera System

			COOLPIX 8700/5700	COOLPIX 5400	COOLPIX 5200/4200	COOLPIX 4500	COOLPIX 4300	COOLPIX SQ	COOLPIX 3700	COOLPIX 3200/2200	COOLPIX 3100/2100
Converter Lenses	Fisheye Converter FC-E8 (0.21x)		-	-	-	●	● w/UR-E4	-	-	-	-
	Fisheye Converter FC-E9 (0.2x)		● w/UR-E12	● w/UR-E10	-	-	-	-	-	-	-
	Wideangle Converter WC-E63 (0.63x)		-	-	-	●	● w/UR-E4	-	-	-	-
	Wideangle Converter WC-E68 (0.68x)		-	-	-	● w/UR-E7	● w/UR-E4& UR-E7	-	-	-	-
	Wideangle Converter WC-E80 (0.8x)		● w/UR-E8	● w/UR-E9	-	-	-	-	-	-	-
	Telephoto Converter TC-E15ED (approx. 1.5x)		● w/UR-E8	● w/UR-E9	-	-	-	-	-	-	-
	Telephoto Converter TC-E2 (approx. 2x)		-	-	-	●	● w/UR-E4	-	-	-	-
	Telephoto Converter TC-E3ED (approx. 3x)		-	-	-	●	● w/UR-E4	-	-	-	-
Slide Copy Adapter	Slide Copy Adapter ES-E28		-	● w/UR-E11	-	●	● w/UR-E4	-	-	-	-
LCD Hoods	LCD Hood HL-CP10		-	-	-	●	-	●	-	-	-
	LCD Hood HL-E885		-	-	-	-	●	-	-	-	-

Converter Adapters



Step-Down Ring Lens Adapter UR-E4
(for COOLPIX 4300)



Step-Down Ring Lens Adapter UR-E7
(for COOLPIX 4500/4300)



Lens Adapter UR-E8
(for COOLPIX 8700/5700)



Step-Down Ring Lens Adapter UR-E9
(for COOLPIX 5400)



Step-Down Ring Lens Adapter UR-E10
(for COOLPIX 5400)



Step-Down Ring Lens Adapter UR-E11
(for COOLPIX 5400)



Step-Down Ring Lens Adapter UR-E12
(for COOLPIX 8700/5700)



Lens Hood HR-E5700
(for COOLPIX 8700/5700)


























Lens Hood HN-CP10
(for COOLPIX 5400)



Lens Hood HN-CP11
(for COOLPIX 8700/5700)

Lens Hood

Nikon COOLPIX Accessories

			COOLPIX 8700/5700	COOLPIX 5400	COOLPIX 5200/4200	COOLPIX 4500	COOLPIX 4300	COOLPIX SQ	COOLPIX 3700	COOLPIX 3200/2200	COOLPIX 3100/2100
Brackets	Multi-Flash Bracket Unit SK-E900 		-	-	-	●	-	-	-	-	-
	Bracket Set SK-9 		*2	*2	-	*1	*2	-	-	-	*2
Speed-lights	Nikon Speedlight SB-800 		●	●	-	● w/SK-E900	-	-	-	-	-
	Nikon Speedlight SB-600 		●	●	-	●	-	-	-	-	-
	Nikon Speedlight SB-30 		●	●	-	*3	*3	-	-	-	*3
Macro Light	MACRO COOL-LIGHT SL-1 		-	-	-	●	● w/UR-E4	-	-	-	-
Power Sources	AC Adapter/Battery Charger EH-21 		●	●	-	●	●	-	-	-	-
	AC Adapter EH-53 		●	●	-	●	●	-	-	-	-
	AC Adapter EH-61 		-	-	-	-	-	●	-	●	●
	AC Adapter EH-62A 		-	-	●	-	-	-	●	-	-
	AC Adapter EH-62B 		-	-	-	-	-	-	-	●	●
	Battery Charger MH-52 (for EN-EL1) 		●	●	-	●	●	-	-	-	-
	Battery Charger MH-53 (for EN-EL1) 		●	●	-	●	●	-	-	-	-
	Car Battery Charger (12V DC in) MH-53C (for EN-EL1) 		●	●	-	●	●	-	-	-	-
	Battery Charger MH-60 (for EN-EL2) 		-	-	-	-	-	●	-	-	-
	Battery Charger MH-61 		-	-	●	-	-	-	●	-	-
	Battery Charger MH-70 (for EN-MH1) 		-	-	-	-	-	-	-	●	●
	Rechargeable Li-ion Battery EN-EL1 		●	●	-	●	●	-	-	-	-
	Rechargeable Li-ion Battery EN-EL2 		-	-	-	-	-	●	-	-	-
	Rechargeable Li-ion Battery EN-EL5 		-	-	●	-	-	-	●	-	-
	Rechargeable Ni-MH Battery EN-MH1 		-	-	-	-	-	-	-	●	●
	Battery Pack MB-E5700 (six R6 [AA] size Batteries) 		●	-	-	-	-	-	-	-	-
	Remote Cord	Remote Cord MC-EU1 (0.8m) 		●	●	-	●	●	-	-	-

*1 Compatible with Nikon Speedlight SB-800/600/30 only.

*2 Compatible with Nikon Speedlight SB-30 only.

*3 Wireless remote flash function is available by built-in flash sensor.



NIKON CORPORATION

Fuji Bldg., 2-3, Marunouchi 3-chome, Chiyoda-ku,
Tokyo 100-8331, Japan

<http://nikonimaging.com/>

Specifications and equipment are subject to change without any notice or obligation on the part of the manufacturer. April 2004
© 2002-2004 NIKON CORPORATION